


Making the simplest Transmitter with a microphone



Caution! You can't use microphone and line-in together. You have to select one side or the other.

soldered point:





Solder every part at the shortest distance. coil 3 - 4 turns by coated 0.8 mm wire

> 5 - 7mm ⅃ℿĹ

registers

470 Ω (yellow-violet-brown) **10K** Ω (brown-black-orange) 2 pieces **27K** Ω (red-violet-orange)

capacitors

10 PF

0.01 or (103)

2 pieces 1 ∝F

- trimmer capasitor 20-50PF
- condensor microphone unit
- **4.7-10K**Ω